



Bucket equipment
for construction

WEAR CAP



Chapeau



WEAR CAP

Chapeau

PA



SIZE Taille	CODE Référence	WEIGHT (kg/lb)	DIMENSIONS (mm/inch)					
			A	B	C	D	E	F
10	TKN10 PA	3,07 / 6,77	168 / 6,61	98 / 3,86	43 / 1,69	24 / 0,94	102 / 4,02	126 / 4,96
11	TKN11 PA	5,36 / 11,82	201 / 7,91	11 / 0,43	51 / 2,01	30 / 1,18	115 / 4,53	142 / 5,59
13	TKN13 PA	6,8 / 14,99	278 / 10,94	124 / 4,88	55 / 2,17	36 / 1,42	137 / 5,39	158 / 6,22
15	TKN15 PA	9,3 / 20,50	236 / 9,29	151 / 5,94	62 / 2,44	34 / 1,34	143 / 5,63	175 / 6,89
17	TKN17 PA	17,0 / 37,48	276 / 10,87	172 / 6,77	74 / 2,91	42 / 1,65	164 / 6,46	197 / 7,76
19	TKN19 PA	27,0 / 59,52	345 / 13,58	215 / 8,46	97 / 3,82	55 / 2,17	192 / 7,56	244 / 9,61
	TKN19 PA CC*	27,95 / 61,62	345 / 13,58	215 / 8,46	97 / 3,82	55 / 2,17	192 / 7,56	244 / 9,61

* Use only with a Cast Corner Adapter

FEURST - BD DE LA BOISSONNETTE - 42110 FEURS - FRANCE - TEL +33 (0)4 77 27 40 63
WWW.TURNKEYTEETH.COM - TECHNICAL-SERVICES@SAFE-FEURST.FR

